



Instruction to Subcontractor

Form: 310-11
Rev: 2

Project Title: 210 Pentonville Rd	Instruction No: 19
Contract No.: HLN 0215	Instruction No:
To: Raphael contracting	Date: 22.04.09

You are hereby instructed to proceed with the work described below which is to be carried out in accordance with the terms and conditions of your subcontract. The number at the top of this instruction must be quoted in all subsequent documents concerning this work.

TICK BOX AS APPROPRIATE

<input type="checkbox"/>	As attached Architects's Instruction –	AI No.	N/A	(item no)
<input type="checkbox"/>	As attached Confirmation of Verbal Instruction -	CVI No.	TBC	(item no)
<input type="checkbox"/>	As attached Request for Information –	RFI No.	N/A	(item no)

X As the following written text:

Item No	Description of Work;
1	Supply and fit upvc cover strip to the end of all baths in the residential block. Size range from 25-50mm.
2	Provide laminate to both sides of the following doors DG 18,20,34,35,36,39.RDG 10,11,12 Provide laminate doors both sides to RDG 06,07,13,14.

Signed M George name M George senior site manager
for BAM Construction

Distribution

<input checked="" type="checkbox"/> Subcontractor HO	<input checked="" type="checkbox"/> Subcontractor Site	<input checked="" type="checkbox"/> Project File	<input checked="" type="checkbox"/> Surveyor	<input type="checkbox"/> other (specify)
--	--	--	--	--